




Onda VI10 Battery Replacement

This guide is to show how to replace the battery in a Onda VI10.

Written By: Clint Richards



INTRODUCTION


This guide is to show how to replace the battery in a Onda VI10.



TOOLS:

- [Soldering Station](#) (1)
 - [Heat Gun](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery




- Use a number 0 screw driver to remove the four screws.

Step 2




- Power Button on the side should be pointing outward.
- Note: This is so the ribbon cables are not damaged.

Step 3




- Heat up the back of the device with a hair dryer to loosen the glue.

Step 4



- Pry up battery from plastic using a nylon spudger or plastic opening tool.

Step 5



- Desolder the two battery cables from the mother board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-03 04:38:06 AM.